

TECHNICAL BULLETIN

For Auger Unloading Collars: A-71333439 and A-71339770

The improved Loewen Auger Unloading Collar features nylon rotating plates instead of ball bearings, to eliminate clogging and reduce abrasive friction.

For L & M series combines, there are two different types of collar chain attachments.

Figure 1 - EARLY MODEL

Chain is attached to collar on a welded block.

If you have an early model combine, ensure there are enough chain links to tie the ends together and allow for some slack.



Figure 1 L, S/N -26000
M, S/N -24700

Figure 2 - LATE MODEL

Chain is threaded through a set of bolts which tighten chain. Same as Auger Unloading Collar received.




Figure 2 L, S/N 26001-
M, S/N 24701-

